

GL-160L-B3
Mounting diagram



GL-160L-B5
Mounting diagram